



## XP SPINDLE SPACERS

### INSTALLATION INSTRUCTIONS

- 1 - With skis aligned to manufacturers specifications, tie skis and handlebar so they cannot move during the installation.
- 2 - Remove bolt from one tie rod end.
- 3 - With new hardware, bolt spindle spacer to the spindle tab and snug up nut but don't tighten.
- 4 - Apply a removable thread locker (e.g. Loctite) to the setscrews and install with 1/8" Allen key and make snug. The setscrews can be adjusted to maintain alignment while eliminating any side-to-side play.
- 5 - Install and tighten second bolt up through the spacer and secure the tie rod end with original washers being re-used. Some setscrew adjustment may be required to fit tie rod end into spacer.
- 6 - Torque nuts to 35 lb/ft. with 17mm socket and torque wrench. Use 6mm Allen key for the bolt.
- 7 - Repeat procedure for the second spacer.

